

Sierra Hardwood Floor Disassembly

1. **Always** Disassemble Opposite of Installation. From Lower Right Corner Working Your Way to Upper Left Corner.
2. **NEVER LIFT PANELS WHILE DISASSEMBLING**
3. To Remove Transitions, Loosen Screw On Bottom Corners, Then Remove Corners. Two of the Corner Transitions Have A Notch In Them. Insert One End of the Floor Tool Into the Notch and Pull. Once these Corners Have Been Removed, You are Ready to Move On To the Next Step.
4. Take Rubber Mallet and Tap Transition. This Should Loosen Transition. If Not, Tap Again (Note: It Could Take Several Taps). Top and Bottom Transitions Tap to the Left, and Side Transitions Tap Down.
5. Every Panel Will Have A BLACK FOOT. **Always** Pull On that Foot for Easy Disassembly with Supplied Disassembly Tool.
6. **Always** Place Panels, By Type, Back In Crates As You Disassemble. This Will Make It Easier for Your Next Installation.
7. When Placing Panels Back In Crates, **Make Sure** the **First Panel** is **Face UP**